



PIN	SYMBLE
1	LEDA
2	LEDK1
3	LEDK2
4	GND
5	VCI
6	RESET
7	NC
8	NC
9	SDA
10	SCK
11	CS
12	PCLK
13	DE
14	VSYN
15	HSYN
16~33	DB0~DB17
34	GND
35	TP_INT
36	TP_SDA
37	TP_SCL
38	TP_RESET
39	TP_VCI
40	GND